Object :

Most of old IR Remote controllers such RC2, RC2i, RC3, RC3i, RC4, RC4i, RC7 and RC7i are phase out.

We still have demands on these remote so we found an alternative by using RC08W.

However this remote must be configured to operate properly

Explanation :

There are 3 categories of product so check other back side of the remote controller if :

Type of remote controller	Setting
RC2, RC3, RC4, RC5, RC7	003
RC2i, RC3i, RC4i, RC7i	002
Special application wine cellar	004

Procedure to set IR remote controller RC08W

Step 1 :
IR remote controller is ON

Hold Clear and Timer buttons during 3 to 5 seconds

LCD screen will display the current setting

Step 2 :
Press on Temp+ or Temp- buttons to change the setting.

Step 3 :
Press on Clear button to save the setting in the EEPROM then it comes back to normal operation